

5. Setup the Aprisa SRi radio

The Aprisa SRi has a factory default Terminal Operating Mode of Remote Station.

One radio in the Aprisa SRi network must be setup as a Base Station.

The other radios in the Aprisa SRi network are setup as Remote Stations.

Set the Ethernet Operating Mode required.

Set the unique radio Network ID to be the same in your entire network including the Base Station ID.

Set the Aprisa SRi TX Power and Channel Size to comply with your site license.

Setup the Aprisa SRi Zones.

Specific channels within the selected zone hop can be disabled if there is a known transmission within the channel that may cause interference to the operation of this network. The minimum number of enabled channels is 50.

If a channel is selected in a zone that is disabled, the zone will be enabled when the channel selection is saved. The default is all zones enabled.

The zone frequencies are pre-defined in the Aprisa SRi for the zone number. The zone frequencies are spaced at the hop frequency of 62.5 kHz.

You can now configure the remaining terminal and network parameters and settings. Please refer to the Aprisa SRi User Manual for detailed instructions.

6. Monitor the Aprisa SRi radio signal strength

When the network is installed, the radio signal strength can be monitored on remote stations by setting the radio to Test Mode.




To enter Test Mode, press and hold the TEST button on the radio LED panel until all the LEDs flash green (about 3 - 5 seconds).

In Test Mode, the LED Display panel presents a real time visual display of the RSSI. This can be used to adjust the antenna for optimum signal strength.


Note: The response time is variable and can be up to 5 seconds.

To exit Test Mode, press and hold the TEST button until all the LEDs flash red (about 3 - 5seconds).

The OK, MODE and AUX LEDs will be solid green and the TX and RX LEDs will be solid or flash green if the network is operating correctly.




| Zones | Zone 1 | Zone 2 | Zone 3 | Zone 4 | Zone 5 | Zone 6 | Zone 7 | Zone 8 |
|-------|-------------------------------------|-----------------------|------------------|--------|--------|--------|--------|--------|
| Zone | Enabled | Frequencies (MHz) | Channels Enabled | | | | | |
| 1 | <input checked="" type="checkbox"/> | 902.53125 - 905.59375 | 50 of 50 | | | | | |
| 2 | <input checked="" type="checkbox"/> | 905.65625 - 908.71875 | 50 of 50 | | | | | |
| 3 | <input checked="" type="checkbox"/> | 908.78125 - 911.84375 | 50 of 50 | | | | | |
| 4 | <input checked="" type="checkbox"/> | 911.90625 - 914.96875 | 50 of 50 | | | | | |
| 5 | <input checked="" type="checkbox"/> | 915.03125 - 918.09375 | 50 of 50 | | | | | |
| 6 | <input checked="" type="checkbox"/> | 918.15625 - 921.21875 | 50 of 50 | | | | | |
| 7 | <input checked="" type="checkbox"/> | 921.28125 - 924.34375 | 50 of 50 | | | | | |



For more information, please refer to the Aprisa SRi User Manual available from the 4RF website www.4rf.com/secure/ (login required).

Aprisa SRi Quick Start Guide 1.2.0 © 2018 4RF Limited. All rights reserved. This document is protected by copyright belonging to 4RF Limited and may not be reproduced or republished in whole or part in any form without the prior written permission of 4RF Limited. While every precaution has been taken in the preparation of this literature, 4RF Limited assumes no liability or errors and omissions, or from any damages resulting from use of this information. The contents and any product specifications within it are subject to revision due to ongoing product improvements and may change without notice. Aprisa and the 4RF logo are trademarks of 4RF Limited. All other marks are the property of their respective owners.

Aprisa SRi



Quick Start Guide

Aprisa SRi Radio

Contents

Follow these steps to operate your Aprisa SRi radio:

1. Check the box contents
2. Install the Aprisa SRi radio and connect the protection earth
3. Connect the Antenna and apply power to the Aprisa SRi radio
4. Connect to the Aprisa SRi radio
5. Setup the Aprisa SRi radio
6. Monitor the Aprisa SRi radio signal strength

1. Check the box contents

The Aprisa SRi is shipped to you in a box containing the following:

Aprisa SRi radio fitted with power connector



USB Cable USB A to USB micro B, 1m

Used for Command Line Interface management see Aprisa SRi User Manual




2. Install the Aprisa SRi radio and connect the protection earth


The Aprisa SRi has four threaded holes (M4) in the base and two holes (for M5 screws) through the enclosure for mounting. Mounting options include:

- DIN rail mounting with the Aprisa SRi Mounting Bracket (optional accessory part number 'APSB-MBRK-DIN')
- Wall and rack shelf mounting
- Outdoor enclosures


The Aprisa SRi mounting options are shown below:




DIN Rail Vertical Mount




DIN Rail Flat Horizontal Mount



DIN Rail Horizontal Mount



Wall Mount



Rack Shelf Mount

The Aprisa SRi has an earth connection point on the top left and the top right of the enclosure. Use the supplied M4 screws to earth the enclosure to a protection earth.

The antenna feeder cable should use grounding kits for lightning protection as specified or supplied by the coaxial cable manufacturer to properly ground or bond the cable outer.



Warning: If the Aprisa SRi is operated in an environment where the ambient temperature exceeds 50°C, the Aprisa SRi must be installed within a restricted access location to prevent human contact with the enclosure heatsink.

3. Connect the antenna and apply power to the Aprisa SRi radio

Connect the antenna to the antenna port TNC female connector. If the antenna is not available, terminate the 'TX / Ant' port with a TNC male 50 ohm terminator (10 Watts min).

Warning: Do not directly connect the two radio antenna ports without attenuation of at least 40 dB. The receiver can be damaged if signals greater than +10 dBm are applied to the antenna port.

The Aprisa SRi is operated from a DC source of voltage between +10 VDC and +30 VDC (negative earth) and consumes up to 35 Watts. External power supplies are available from 4RF as accessories (see the Aprisa SRi User Manual).

The power connector (Molex 2 pin female) is supplied fitted to the radio. Wire your power source to the power connector (- / +) and plug the connector into the radio. The connector screws should be fastened to secure the connector.

Note: The radio fuses will blow if the connected power supply is over voltage or the polarity is reversed. Two spare fuses are located inside the enclosure (see the 'Spare Fuses' section of the Aprisa SRi User Manual).

Turn your power source on. The radio LEDs will flash orange for one second and then the OK, MODE, AUX LEDs will light solid green and the TX and RX LEDs will flash red. This is because the factory default Terminal Operating Mode for all Aprisa SRi radios is set to Remote Station.

When the radio has been configured and has registered with the network, the TX and RX LEDs will be solid or flash green if the network is operating correctly.

The Aprisa SRi radio is ready to operate.

Warning: On link operation, RF energy is radiated from the antenna. Do not stand in front of the antenna.



4. Connect to the Aprisa SRi radio

The Aprisa SRi has a factory default IP address of 169.254.50.10 with a subnet mask of 255.255.0.0.

Each radio in the Aprisa SRi network must be setup with a unique IP address on the same subnet.

If the IP address of the radio is unknown, it can be changed via the Command Line Interface on the radio MGMT USB port:


- Connect your PC USB port to the Aprisa SRi MGMT USB port. USB to UART Bridge VCP Drivers are required to connect the radio USB port to your PC. You can download and install the relevant driver from <https://www.silabs.com/products/development-tools/software/usb-to-uart-bridge-vcp-drivers>.
- Login to the radio with the default login 'admin' and password 'admin'.
- At the command prompt >> type 'cd APRISASR-MIB-4RF' and enter.
 - type 'set termEthController1IpAddress xxx.xxx.xxx.xxx' and enter.
 - type 'set termEthController1SubnetMask 255.255.0.0' and enter.
 - type 'set termEthController1Gateway xxx.xxx.xxx.xxx' and enter.

If the IP address of the radio is known or is the default IP address, it can be changed via the Ethernet port:

- Setup your PC for a compatible IP address e.g. 169.254.50.1 with a subnet mask of 255.255.0.0.
- Connect your PC network port to one of the Aprisa SRi Ethernet ports.
- Open a browser and enter <https://169.254.50.10>.

Note: The Aprisa SRi has a Self Signed security certificate which may cause the browser to prompt a certificate warning. It is safe to ignore the warning and continue. The valid certificate is 'Issued By: 4RF-APRISA' which can be viewed in the browser.

- Login to the radio with the default login 'admin' and password 'admin'.
- Change the IP address, Subnet mask and Gateway to network compatible IP addresses.



The screenshots show the 4RF Supervisor web interface. The first screenshot is the login page with a 'LOGIN' form containing fields for 'Username' (admin) and 'Password', and a 'Login' button. The second screenshot shows the 'IP Setup' configuration page under the 'NETWORKING IP SETTINGS' section, with the IP Address field set to 172.10.1.30, Subnet Mask set to 255.255.0.0, and Gateway IP Address set to 0.0.0.0. The IP Address field is circled in red.